



FIG. 6



200

FIG.7



Unified M	lanager
Call Forw	ard
Setting	Value
Fwd no answer to	
Fwd on busy to	
300 FIG.	O A

Unit	fied Manager
Cal	l Forward
Setting	Value
Fwd no answer to	221
Fwd no answer delay	2
FWD on busy to	
	,
360	

FIG.9B

ified Manager
Network
Value
10. 10. 10. 1
255. 255. 255.0
47. 20. 189. 40
255. 255. 240.0

340

FIG.9C

Unified Manager		
Telephony		
Setting	Value	
Mobility option	Etiquette	
Carrier option	E1	
Software Version	Etiquette E1	
Region	NA	
Start DN length	3	
Start DN	221	

320

FIG.9D




FIG. 10A




FIG. 10B




FIG. 10C

